


Schlagschrauber E 24 P3
Impact wrench
29908 31 5

MANNESMANN
DEMAG

Nr.	Benennung	Description	Artikel-Nr.	Stück
1	Schraube	Screw	9304 033	8
2	Federring	Lock washer	9314 008	8
3	Schlagwerksgehäuse	Housing cpl.	29910 03 6	1
4	Dichtung	Gasket	29910 04 6	1
5	Büchse	Bushing	29602 81 6	1
6	Klemmring	Clamping ring	039 259 74	1
7	Runddichtring	Seal ring	039 262 74	1
8	Amboss	Anvil	29910 05 6	1
9	Nutwelle	Axle	29602 82 6	1
10	Kupplungsfeder	Spring	29602 63 6	1
11	Schlaggewicht	Impact weight	29910 06 6	1
12	Nocken	Cam	29910 07 6	1
13	Nutwellensitz	Axle seat	29910 08 6	1
14	Schwungrad	Flywheel	29910 09 6	1
15	Kugellager	Ball bearing	9357 026	1
16	Dichtung	Gasket	29910 10 6	1
17	Gehäuse	Housing	29910 11 6	1
18	Kugellager	Ball bearing	9357 087	1
19	Lagerschild	End plaate	29910 12 6	1
20	Stift	Pin	039 324 74	1
21	Zylinder	Cylinder	030 147 74	1
22	Rotor	Rotor	29910 13 6	1
23	Lamelle	Vane	030 149 74	5
24	Spannhülse	Sleeve	9315 721	1
25	Lagerschild	End plaate	29910 14 6	1
26	Kugellager	Ball bearing	9357 025	1
27	Dichtung	Gasket	039 260 74	1
28	Gehäusedeckel	housing cover	039 438 74	1
29	Feder	Spring	030 023 74	2
30	Kugel	Ball	9357 912	2
31	Spannstift	Pin	030 024 74	3
32	Regulierung	Regulation	039 237 74	1
33	O-Ring	O-ring	030 021 74	1
34	Runddichtring	Seal ring	039 239 74	1
35	Umsteuerventil	Reverse valve	039 223 74	1
36	Ventilbüchse	Valve bushing	039 224 74	1
37	Tülle	Spout	29910 15 6	1
38	Siebträger	Strainer support	29910 16 6	1
39	Schalldämpfer	Silencer	039 435 74	1
40	Runddichtring	Seal ring	29910 17 6	1
41	Runddichtring	Seal ring	039 240 74	3
42	Büchse	Bushing	039 210 74	1
43	Runddichtring	Seal ring	9319 007	1
44	Ventil	Valve	039 211 74	1
45	Drücker	Trigger	039 222 74	1
46	Spannhülse	Sleeve	9315 714	1
47	Walzenstift	Pin	29910 18 6	1
48	Walze	Roll	29603 17 6	1



E 24 P3

29908 3 15