

**Winkelschrauber
AW 12 - 301 UA
29900 35 6**

**MANNESMANN
DEMAG**

Nr. No.	BENENNUNG	DESCRIPTION	Lager-Nr. Stock-No.	STÜCK QTY.
1	Gehäuse	Housing	29918 49 6	1
2	Mutter	Nut	29918 50 6	1
3	O-Ring	O-Ring	29918 51 6	1
4	Sicherungsring	Circlip	29915 50 6	1
5	Kugellager	Bearing	29916 76 6	1
6	Feder	Spring	29918 52 6	1
7	Distanzring	Spacer	29931 28 6	1
8	Distanzring	Spacer	29931 29 6	1
9	Nadellager	Needle roller bearing	29931 30 6	2
10	Antriebswelle	Bevel gear compl.	29931 31 6	1
11	Mutter	Nut	29918 56 6	1
12	Winkelkopf	Angle head	29931 32 6	1
13	Nadellager	Needle roller bearing	29931 33 6	1
14	Distanzring	Spacer	29931 34 6	1
15	Kugellager	Bearing	29931 35 6	1
16	Sicherungsring	Circlip	29931 36 6	1
17	Mutter	Nut	29931 37 6	1
18	Sicherungsring	Circlip	29916 94 6	1
19	Mutter	Nut	29919 19 6	1
20	Regler	Clutch regulation	29916 83 6	1
21	Feder	Spring	29918 61 6	1
22	Sicherungsring	Circlip	29916 93 6	1
23	Feder	Spring	29916 95 6	1
24	Hülse	Bush	29916 97 6	1
25	Steuerhülse	Fixed clutch	29804 03 3	1
26	Kugel	Ball	29916 99 6	3
27	Mitnehmer	Fixed clutch	29804 04 3	1
28	Kupplungswelle	S Clutch Screwdriver	29918 62 6	1
29	Kugel	Ball	29916 87 6	4
30	Stift	Pin	29916 98 6	3
31	Kugel	Ball	29916 87 6	14
32	Kupplung	Clutch	29931 38 6	1
33	Distanzring	Spacer	29919 22 6	1
34	Sicherungsring	Circlip	29931 39 6	1
35	Kugellager	Bearing	29918 66 6	2
36	Nadelkäfig	Needle cage	29917 22 6	3
37	Planetenrad	Gear wheel	29917 23 6	3
38	Stift	Pin	29918 68 6	3
39	Planetenradträger	Planet shaft	29931 40 6	1
40	Distanzring	Spacer	29918 70 6	1
41	Nadelkäfig	Needle cage	29916 71 6	3
42	Planetenrad	Gear wheel	29918 71 6	3
43	Planetenradträger kompl.	Planet shaft compl.	29918 72 6	1
44	Kugellager	Bearing	29918 73 6	1
45	Sicherungsring	Circlip	29918 74 6	1
46	Schalldämpfer	Silencer	29918 75 6	1
47	Gehäuse kpl.	Tube compl.	29931 41 6	1
48	Hülse	Cursor	29918 77 6	1
49	Kugellager	Bearing	29916 59 6	1
50	Lagerschild, hinten	Cylinder upper plate	29918 78 6	1
51	Lamelle	Vane	29918 79 6	5
52	Rotor	Rotor	29918 80 6	1

Nr. No.	BENENNUNG	DESCRIPTION	Lager-Nr. Stock-No.	STUCK QUTY.
53	Stift	Pin	29916 54 6	1
54	Zylinder	Cylinder	29918 81 6	1
55	Lagerschild, vorn	Cylinder lower plate	29918 82 6	1
56	Kugellager	Bearing	29918 83 6	1
57	Feder	Spring	29918 84 6	1
58	Mutter	Nut	29918 85 6	1
59	Deckel	Cover	29918 86 6	1
60	O-Ring	O-Ring	29918 87 6	1
61	Dämpfring	Filter ring	29918 88 6	3
62	Schalldämpfer	Silencer	29918 89 6	3
63	Siebträger	Connector	29918 90 6	1
64	Filter	Filter ring	29916 47 6	1
65	Feder	Spring	29918 91 6	1
66	Ventil	Valve	29918 92 6	1
67	Buchse	Bushing	29918 93 6	1
68	Distanzring	Spacer	29918 94 6	1
69	Schalldämpfer	Silencer	29918 95 6	1
70	Filter	Filter ring	29918 96 6	2
71	Hebel	Lever	29918 97 6	1
72	Stift	Pin	29918 98 6	1
73	Ventilgehäuse	Control top	29918 99 6	1
74	Stift	Pin	29916 54 6	1
75	Ventil kpl.	Valve compl.	29919 00 6	1
76	O-Ring	O-Ring	29919 01 6	1
77	Feder	Spring	29919 02 6	1
78	Hülse	Spacer	29919 03 6	1
79	O-Ring	O-Ring	29916 53 6	1
80	Kugel	Ball	29916 56 6	1
81	Feder	Spring	29916 57 6	1
82	Lufteinlaßstück	Distributor	29916 55 6	1
83	Umschaltchieber	Inverter button	29916 51 6	1
84	Schraube	Screw	29919 04 6	1

AW 12 - 301 UA
29900 35 6

