


**Winkelschrauber
Screwdriver
AW 8 - 602 UA
29939 31 6**

**MANNESMANN
DEMAG**

Nr. No.	BENENNUNG	DESCRIPTION	Lager-Nr. Stock-No.	Stk. QTY.
1	Kupplungsgehäuse	cluth case	29919 50 6	1
2	Mutter	nut	29919 06 6	1
3	O-Ring	O-Ring	29915 76 6	1
4	Sicherungsring	spring	29919 07 6	1
5	Kugellager	bearing	29915 78 6	1
6	Hülse	spacer	29919 08 6	1
7	Sicherungsring	spring	29919 09 6	1
8	Nadellager	needle roller bearing	29919 10 6	1
9	Dichtung	ring	29919 11 6	1
10	Kegelradspindel	bevelgear compl.	29919 51 6	1
11	Mutter	nut	29919 13 6	1
12	Winkelkopf	angle head	29919 14 6	1
13	Nadellager	needle roller bearing	29919 15 6	1
14	Kugellager	bearing	29919 16 6	1
15	O-Ring	O-Ring	29919 17 6	1
16	Mutter	nut	29919 18 6	1
17	Sicherungsring	circlip	29916 94 6	1
18	Mutter	nut	29918 60 6	1
19	Regler	regulation clamp	29916 83 6	1
20	Druckfeder	spring	29804 02 3	1
21	Sicherungsring	circlip	29916 93 6	1
22	Feder	spring	29916 95 6	1
23	Hülse	bushing	29916 97 6	1
24	Steuerhülse	fixed clutch	29804 03 3	1
25	Kugel	ball	29916 99 6	3
26	Mitnehmer	fixed clutch	29804 04 3	1
27	Kupplungswelle	screwdriver spindle	29918 62 6	1
28	Kugel	ball	29916 87 6	18
29	Stift	pin	29916 98 6	3
30	Kupplung	clutch	29919 52 6	1
31	Distanzring	spacer	29919 53 6	1
32	Planetenrad	gear wheel	29919 54 6	1
33	Planetenrad	gear wheel	29916 74 6	3
34	Mittlere Welle	middle shaft	29919 55 6	1
35	Sicherungsring	circlip	29919 56 6	1
36	Nadelkäfig	needle cage	29916 71 6	6
37	Planetenrad	gear wheel	29916 74 6	3
38	Welle hinten	end shaft	29919 57 6	1
39	Zahnkranz	gear ring	29919 58 6	1
40	Sicherungsring	circlip	29919 29 6	1
41	Kugellager	bearing	29919 30 6	1
42	Distanzring	spacer	29919 31 6	1

Nr. No.	BENENNUNG	DESCRIPTION	Lager-Nr. Stock-No.	Stk. QUTY.
43	Sicherungsring	circlip	29931 39 6	1
44	Schalldämpfer	silencer	29919 32 6	1
45	Gehäuse	tube	29949 27 6	1
46	Gleithülse	cursor	29949 28 6	1
47	Kugellager	bearing	29916 59 6	1
48	Lagerschild	cylinder upper plate	29949 29 6	1
49	Lamelle	vane	29919 34 6	5
50	Rotor	rotor	29949 30 6	1
51	Stift	pin	29916 54 6	1
52	Zylinder	cylinder	29919 36 6	1
53	Lagerschild	cylinder lower plate	29949 31 6	1
54	O-Ring	O-Ring	29919 38 6	1
55	Kugellager	bearing	29919 39 6	1
56	Feder	spring	29916 67 6	1
57	Mutter	nut	29916 68 6	1
58	Luftanschluss	connector	29916 46 6	1
59	Filter	filter	29916 47 6	1
60	Feder	spring	29919 40 6	1
61	Ventilstift	valve	29919 41 6	1
62	Büchse	bushing	29919 42 6	1
63	Schalldämpfer	silencer	29919 43 6	1
64	Filter	filter	29919 44 6	3
65	Schalldämpfer	silencer	29919 45 6	1
66	Scheibe	washer	29919 46 6	1
67	Hebel	lever	29949 32 6	1
68	Stift	pin	29918 98 6	1
69	Ventilgehäuse	control top	29919 47 6	1
70	Stift	pin	29916 54 6	1
71	Ventil mit Stift	valve with pin	29919 61 6	1
72	O-Ring	O-Ring	29919 49 6	1
73	Feder	spring	29919 02 6	1
74	Hülse	spacer	29919 03 6	1
75	O-Ring	O-Ring	29916 53 6	1
76	Kugel	ball	29916 56 6	1
77	Feder	spring	29916 57 6	1
78	Lufteinlaßstück	distributor	29916 55 6	1
79	Umschaltchieber	reversibility button	29916 51 6	1
80	Schraube	screw	29919 04 6	1



AW 8 - 602 UA
29939 31 6